



INSTALLATION INSTRUCTIONS FOR SAFETY NET, VOLVO 1800 ES

Part No. 282 764

The safety net can either be fitted behind the front seats or the rear seat backrest.

1. Mark up and drill the holes ($\text{Ø } 3.5 \text{ mm} = 9/64''$) for the upper front attachments as shown in the picture. Start from locking pin A and follow the vertical line upwards. Make sure that the car stands horizontally and use a plumb line. The holes should be drilled at an angle of 45° . The 10 mm value illustrates the 45° angle.
2. Fit the attachments with the help of the screws included in the kit.
3. Fit the safety net in its upper attaching hooks as shown in the picture and fit the attachments on the lower ones.
4. Mark up the holes for the lower attachments so that they come exactly beneath the upper ones.
5. Drill the holes ($\text{Ø } 3.5 \text{ mm} = 9/64''$) and fit the attachments.
6. Mark up and drill the holes ($\text{Ø } 3.5 \text{ mm} = 9/64''$) for the upper, rear attachments as shown in the picture. Start from the rear edge of the backrest (in upright position) and follow the vertical line upwards. The holes should be drilled horizontally.
7. Fit the attachments.
8. Fit the lower, rear attachments in the same way as the front ones.

