

# LUCAS

## EQUIPMENT & SPARE PARTS

Spares List No.

1973

N.V.S.

March 1963

VOLVO  
P1800

### SPARE PARTS

Further to N.V.S.1916 this vehicle is now being produced in Sweden, equipment is as shown below:-

BULBHOLDER, CLOCK ILLUMINATION AND PANEL LIGHT		Headlamp 58651B cont'd...	
Part No.	54944812	§ Nut, rim fixing screw 187117	
Bulb	‡987	Bracket, fixing rim 555704	
BULBHOLDER, MAP LIGHT		§ Plate, retaining light unit 54520549	
Part No.	554734	Screw, fixing unit retaining plate 186137	
Bulb	‡987	Rim, unit seating 54520446	
FLASHER UNIT		§ Gasket, body 54520711	
Part No.	35020A	§ Adaptor 553738	
Model	FL5	Spring, fixing unit seating rim 54520514	
FUSE BOXES		Screw, trimmer 54520451	
Part No.	54038033	Housing, trimmer screw nut 54520550	
Model	4FJ	Nut, trimmer screw 54520551	
§ Fuse, 35 amp.	188218	LAMP, NUMBER PLATE ILLUMINATION AND REVERSE	
§ Cover	54380114	Part No.	53999A
§ Screw, terminal	120560	Model	706
Part No.	54038035	§ Cover	54573363
Model	5FJ	Screw, fixing cover	186194
§ Fuse, 35 amp.	188218	§ Glass, number plate illumination	54573680
§ Cover	54380108	§ Glass, reverse	54573364
LAMP, HEAD (Less Light Unit)		§ Gasket, seating glass	54573366
Part No.	‡58651B *	§ Bulbholder, number plate illumination	554710
Model	F700 Mk X	Interior, bulbholder	553780
§ Rim or door	54521155	Ring, seating bulbholder	554354
§ Screw, fixing rim	198898	Bulb, number plate illumination	989
§ Washer, retaining screw	161385	Bulbholder, reverse	556284
		Interior, bulbholder, reverse	573832
		Bulb, reverse	382

Continued...

JOSEPH LUCAS LTD · BIRMINGHAM 18 · ENGLAND



Number Plate Illumination and Reverse Lamp 53999A cont'd...

Gasket, seating lamp	54573367
Grommet, cable entry	574049
Grommet, cable entry	54572247
Body	54573368

LAMP, SIDE AND FLASHER

Part No.	752592A/D
Model	714
Rim or door with lens	754573428
Lens	754574026
Gasket, seating lens	576805
Sliding ring	574616
Interior, bulbholder, flasher	573832
Bulb, flasher	382
Interior, bulbholder, side	553780
Bulb, side	989
Gasket, seating lamp	754573429
Body	754573372
Nut, fixing lamp	54131266
Washer, fixing nut	188330

LAMP, STOP TAIL AND FLASHER  
(Left Hand, Amber & Red)

Part No.	754122B
Model	671
Lens	754573966
Screw, fixing lens	54110101
Washer, retaining screw	164722
Gasket, seating lens	54571195
Interior, bulbholder, flasher	573832
Bulb, flasher	382
Interior, bulbholder, stop tail	573828
Bulb, stop tail	380
Grommet, cable entry, stop tail	54572202
Gasket, seating base	54571804
Gasket, seating lamp	54571811
Base	54571688
Nut, fixing lamp	54131266
Washer, fixing nut	188483
Grommet, cable entry, flasher	54572247

(Right Hand, Amber & Red)

Part No.	754123B
Model	671
Base	54571689
Other details as	54122B.

(Left Hand, Red)

Part No.	53899D
Model	671
Lens	54572039

Stop Tail and Flasher Lamp 53899D cont'd.

§ Grommet, cable entry	576401
Other details as	54122B.

(Right Hand, Red)

Part No.	53901D
Model	671

§ Lens	54572039
Base	54571689

§ Grommet, cable entry	576401
Other details as	54122B.

RELAY, HEADLAMP

Part No.	33188D
Model	6RA

RELAY, HORN

Part No.	33231B
Model	6RA

STEERING COLUMN CONTROL

Part No.	†33566A
Model	CC5

Cover	54300479
§ Plate, contact, upper	54300013
Plate, contact, lower and fixing cup	54300605
Screw, fixing	186136
Knob, Horn Push	54300482

SWITCH, COURTESY

Part No.	31828D
Model	65SA

Nut, fixing	153601
Washer, fixing nut	54148517

SWITCH, DIPPER

Part No.	31800B
Model	21SA

Pad, insulating	360373
-----------------	--------

SWITCH, HEATER FAN

Part No.	*34519A
	(34317)
Model	58SA

Nut, fixing	153636
Washer, fixing nut	186106

Knob	‡54332781
------	-----------

Escutcheon plate(English)	‡54332783
---------------------------	-----------

Escutcheon plate(Swedish)	‡54334687
---------------------------	-----------

Continued...



**SWITCH, HORN**  
 Part No. 34322A  
 Model 23SA  
 Nut, fixing, front 153631  
 Washer, fixing nut 54148517  
 Nut, fixing, rear 153636

**SWITCH, LIGHTING**  
 Part No. 34323B  
 Model 10SA  
 Knob ‡54332781  
 Bezel ‡313630  
 Escutcheon plate (English) ‡54332782  
 Escutcheon plate (Swedish) ‡54334685

**SWITCH, ROOF LAMP**  
 Part No. 31743D/E  
 Model 57SA  
 Nut, fixing 153631  
 Washer, fixing nut 54148517

**SWITCH, STOP LAMP**  
 Part No. 31882B  
 Model HL2

**SWITCH, WINDSHIELD WIPER**  
 Part No. 34324B  
 Model 10SA  
 Knob ‡54332781  
 Bezel ‡313630  
 Escutcheon plate (English) ‡54332784  
 Escutcheon plate (Swedish) ‡54334686

**WARNING LIGHTS**  
 Bulbholder, Flasher, Ignition and Main Beam  
 Part No. 319408  
 Bulb ‡987

**OVERDRIVE**  
 Cover and Window 54360477  
 Shade 319222  
 Bulbholder 554734  
 Bulb 987

**SCREENWIPER SPINDLE BUSH**  
 Part No. 54713111

**SCREENWIPER SPINDLE GASKET**  
 Part No. 54713113

OVERDRIVE EQUIPMENT

**RELAY**  
 Part No. 332  
 Model

**SWITCH, GEARBOX**  
 Part No. 318  
 Model S

**SWITCH, OPERATING**  
 Part No. 318  
 Model 6

Nut, fixing 153  
 Washer, fixing nut 54148  
 Escutcheon plate (English) ‡54334  
 Escutcheon plate (Swedish) ‡54334

**SOLENOID**  
 Part No. 76522  
 Model

Cover, contact 765  
 Cover, rubber 765  
 Boot, rubber, plunger 765  
 Plunger 54640

CABLE SUNDRIES

Eyelet 1/4" 850  
 Eyelet 3/8" 850  
 Eyelet 3/16" 850  
 Eyelet 5/16" 900  
 §Lucar, connector (17.5 amp) 54942  
 Sleeve 54190  
 §Lucar, connector (17.5 amp - double) 54942

Sleeve 54190  
 Nipple, connector 900  
 Tube, connector (2 way) 900  
 Tube, connector (4 way) 850  
 Grommet, diaphragm 863  
 Grommet, handbrake 54948  
 Holder, panel light 54947  
 Holder, panel light 54360

- ¶ New item.
- || Serviced by vehicle manufacturer.
- \* When ordering, quote part number shown in brackets.
- ‡ Order separately.
- † Complete control serviced by vehicle manufacturer.
- § Recommended spares for stock.